


VGA Retro Camera

LOCATION OF CONTROLS



- | | | |
|------------------|----------------|---------|
| 1. Shutter | 2. Viewfinder | 3. Lens |
| 4. USB connector | 5. Mode button | 6. LED |
| 7. Battery Door | 8. LCD display | |

1.0 GETTING STARTED

1. Open the Battery Door and insert one AAA battery into the battery compartment making sure that the battery terminals (+ and -) are properly positioned.
2. Close the Battery Door
3. Press the **Mode** button once, the camera will turn on. The camera will beep once and the LCD will display the picture counter. The counter shows the number of images that are stored in the camera. It will display "00" when the camera is first turned on.

2.0 TAKING A PICTURE

1. Verify the LCD is displaying the number of images taken. If the display is other than a number, press the mode button until a number is displayed. If this is the first time the camera has been activated, the LCD should display "00".
2. Next, look through the camera Viewfinder. Hold the camera steady and press the Shutter button until you hear 2 beeps. A photo was taken successfully.
3. The counter displayed in the LCD will be increased by one each time an image is captured.
4. If the counter did not increase by one it may be because the Shutter button was not pressed properly.
5. Ultimately, "FL" will be shown on the LCD display indicating that the camera memory is full.

3.0 The BATTERY and AUTO STAND-BY MODE

1. The camera will switch to stand-by mode after 60 seconds of inactivity. The LCD will go blank to help conserve battery power.
2. If the camera is in stand-by mode, pressing the Mode button once will bring the camera out of stand-by mode. Any pictures taken will remain in the memory.
3. Any of the following indicates battery need to be replaced :
 - a. The LCD display keep flashing

- b. When you press the "Mode" button, the LCD turns on once then goes off immediately.
- c. When you press the "Mode" button, the LCD display does not turn on at all, it means the battery power is running out and it is time to replace the battery.

Note: Always upload all images to PC before replacing the battery.

Low battery power will effect image quality & performance of the camera.

4.0 ADDITIONAL FEATURES

Press the mode button repeatedly until the desired features are shown on the LCD. Then press the shutter button. If the desired feature is not selected in 5 seconds, the display will be switched back to the Picture Counter.

00 : Picture Counter	
5t : Self Timer	HI : High Resolution (VGA)
dB : Video Clip Recording	Lo : Low Resolution (QVGA)
CS : Continuous Shooting for 3 Images	PU : 1.3M Resolution by Interpolation
CR : Delete All Photos	L9 : Standard Image Quality
CL : Clear Last Photo	H9 : High Image Quality
Ud : Mass Storage Device Mode	60 : 60 Hz
PC : PC Cam Mode	50 : 50 Hz

4.10 Self-Timer

1. Press the Mode button until "5t" appears on the LCD.
2. Press the shutter button to activate a 10 second self-timer.
3. The camera will issue a series beeping sounds and an image is taken successfully when the beeping sound stops.
4. The picture counter will increase by one to indicate that the image has been taken.
5. The Self Timer mode cannot be selected when the camera memory is full.
(i.e. "FL" displayed on the LCD)

4.20 AVI Video Clip

1. Press the Mode button until "dB" is displayed on the LCD, then press the Shutter button to start recording video.
2. The LCD will display a Timer in seconds, starting from "01".
3. The camera allows to take video up to 10 seconds for each clip and maximum for 5 clips. The video recording will stop when the LCD shows "10". Then it will switch back to the picture counter. The picture counter will be increased by one.

4. Video will be recorded in QVGA format (320 x 240).
5. If you want to stop the video recording, press the Shutter button once.
6. The video recording stops when the memory is full, or if the Shutter button is being pressed during recording.

Note: During the AVI mode, the camera automatically adjusts the exposure.

4.30 Continuous Shooting for 3 Images

1. Press the "Mode" button until "CS" is displayed on the LCD, then press the Shutter button to begin Continuous mode.
2. The camera will take 3 images continuously and then stop. The Picture Counter will be increased by one.
3. Continuous shooting stops when the memory is full.

4.40 Clearing the stored images

4.41 Delete All Photos

Press the Mode button until "CR" appears on the LCD. Pressing the shutter button once, you will hear one (1) beep and the picture counter will start flashing. Press the Shutter button once and it will clear all the photos or AVI movies stored in the camera and reset the picture counter to "00".

4.42 Delete Single Photos

Press the Mode button until "CL" appears on the LCD. Press the shutter button once and it will clear the last picture or the last AVI movie.

4.50 Image Resolutions

1. The camera is defaulted with the setting in "HI" - VGA resolution.
There are two resolutions available to select in the camera:

HI : High Resolution. This option will set the resolution to 640 x 480 VGA

Lo : Low Resolution. This option will set the resolution to 320 x 240 QVGA

PU : 1.3M Resolution by Interpolation. This option will set the resolution to 1280 x 960 1.3M Pixels.

2. Press the Mode button until "HI" appears in the LCD display. Then keep pressing the Shutter button will display the following sequence:

Lo → HI → PU

3. Select the desired resolution format then press **Mode** button to confirm the change.

4.60 Image Quality

High Quality and Standard Quality

1. The camera is defaulted with the setting in "H9" High Quality.
2. To set to Standard Quality L9, press the Mode button until H9 appears in the LCD. Press the "Shutter" Button once and the LCD will display L9.
3. Press the Mode button once to confirm the mode change. The L9 Standard Quality is being selected.

Below is a table to show the maximum number of images can be taken at different resolutions with different Image Quality:

Resolutions	High Quality	Standard Quality
H1 (VGA 640 x 480)	70 images	110 images
L0 (QVGA 320 x 240)	170 images	270 images
PU (1.3M by Interpolation)	22 images	35 images

4.70 Frequency Selection- when using as a Web camera (Video mode) or Indoor Image Capturing

50Hz/60Hz Frequency mode

1. Select 50Hz or 60Hz according to the power frequency set in your living country to avoid flickering under video mode or indoor image capturing.
2. The 60Hz frequency is set as a default. To select 50Hz frequency, press the Mode button until "60" is displayed on the LCD, then press the Shutter button to confirm selecting 50Hz.

Remark: It is recommended to choose 60Hz in North America.

5.0 INSTALLING THE SOFTWARE AND UPLOADING IMAGES TO PC

Windows 98 Users

To upload the images to PC, install the camera driver first. After this has been done, the stored images in the camera can be moved to the PC.

Note: Do NOT connect camera to USB port prior to installing software and drivers.

1. Insert the CD into the CD-Rom drive. The installation window automatically appears. Ensure the camera is not connected to your computer.
2. Close out of all programs and disable any background applications such as Anti-Virus software.
3. If the installation window does not appear, click the Start button on the desktop and choose Run.

4. When the Run dialog box appears, click the Browse button and navigate to your CD-ROM drive directory. Double-click the Setup.exe icon to begin the installation process.
5. An Install shield Wizard will be appeared. Click the "Next" button.



6. After the installation is completed, click the "Finish" button and restart the computer.



7. Connect the camera to the PC with the USB cable. "Building Driver Information" & "New Hardware found" dialogue box will open and the computer will recognize the camera.



8. If you can see "Removable Disk" under "My Computer", the camera driver installation is successful.

8.40 VIDEO Conferencing

You can use the digital camera to work as a Webcam to perform Video conferencing:

1. If the net meeting programs are not included in your Explorer®, download "NetMeeting" from www.microsoft.com or "Yahoo® Messenger" from www.yahoo.com.
2. Connect your digital camera and start the net meeting programs. You can see your friends and families if they are on the same net meeting program and have the web camera set up.

9.0 REMOVING THE REMOVABLE DISK

9.10 Windows 98SE


1. Check that the camera is not transferring any files to the PC. Under transmission of files, the LED will light up and flash, wait until the LED on the camera turns off.
2. Unplug the USB cable.

9.20 Windows 2000/ME/XP

1. Check whether the camera and PC are transferring a file and check if the LED is flashing, wait until the LED on the camera turns off.
2. Double click the [Unplug or Eject Hardware] icon on the task bar as show in below :



3. The [Unplug or Eject Hardware] window will open. Select the [USB Disk] and click the [Stop] button.



4. The [Stop a Hardware device] window will open. Select [USB Mass Storage] and click the [OK] button.

5. [Safe to Remove Hardware] window will open. Click [OK] button and the removable disk will be removed safely.



6. Unplug the USB cable.

10.0 HINTS ON SOFTWARE INSTALLATION

The camera driver might share same resource files with other imaging device. In case user encounter difficulties in software installation, uninstall driver of other imaging device and reinstall the camera driver from beginning.

Helpful Hints and Camera Maintenance

Troubleshooting:

1. **The camera does not work:**

- Make sure the battery has inserted with the correct polarity.
- Check if the battery power is low / run out of battery, replace a new one.

2. **"No New Hardware Found" message appears:**

- Make sure the camera and PC are connected properly. Go to "My Computer" icon → Right click your mouse → Choose "Property" → Select "Device Manager" → If you have encounter below two situations :


- (i) "Imaging Device" does not exist under the list
- (ii) The "Imaging Device" is on the list, check out if the driver named "EZ Cam" exist, if not ,

unplug the camera and re-connect the camera into your computer's USB port.


Note: If the camera is listed, but other cameras are also installed, disable all other cameras; make sure your camera is enabled.

3. **"Camera not connected" or "Device cannot be detected" message appears:**

- Try removing the previous driver and reinstalling the software.
Go to "My Computer" icon → Right click your mouse → Choose "Property" → Select "Device Manager" → "Imaging Device" → select the driver "EZCam" and choose "Remove" to uninstall the driver:



Then uninstall the driver program named "EZCam" under the "Add/ Remove program" from the Windows Control Panel and restart the computer. Reinstall the driver again.



4. After installing the camera software, the camera is not detected by the software:
 - Some PC's have been shipped without the USB port mode enabled. To enable the USB Port. You must run the system CMOS setup program. This setup program is only available when you power up the computer. The procedure is different for each system so you will need refer to your PC manual for more details.

5. To Uninstall the Camera Driver:

- To uninstall the Camera Driver, go to Windows Start menu -> Programs-> EZCam-> click "Uninstall".

Camera Maintenance:

Maintaining your camera will ensure longer life and will minimize the chances of causing damage to your camera and computer.

- Keep the camera away from moisture and extreme temperature.
- Clean the outside of the camera with a clean, dry cloth.
- Never use harsh or abrasive cleaners or organic solvents on camera or on any of its parts.
- Never disassemble or touch the inside of the camera.

11.0 ACCESSORIES

Your kit contains the following:

- * Installation CD
- * USB Cable
- * Instruction manual
- * 1 AAA battery
- * Keychain

Note: Your computer needs a USB port to use your digital camera.

12.0 SYSTEM REQUIREMENTS

- PC with Intel Pentium III 800MHz or Higher
- Microsoft Windows 98SE/ME/2000/XP
- 128MB RAM or Higher
- 350MB available hard drive space
- Available USB port
- 24-bit display adaptor
- True Color (24-bit) display settings at 1024 X 768 pixels (recommended)
- 8X or faster CD-ROM drive
- Mouse

Note: When using a USB connection, a PC running window 98 is required to upload pictures from the camera. Window 95 does not support USB connection.

13.0 GENERAL SPECIFICATIONS

- Resolution: 640 x 480 Pixels VGA resolution
320 x 240 Pixels QVGA resolution
1.3M by Interpolation
- Internal Memory: 8MB SDRAM
- Store a maximum 70 VGA images, or
170 QVGA images with High Image Quality, or
22 1.3M images by Interpolation
- Record up to 5 AVI video clips, each at maximum 10 seconds
- Self Timer
- Auto Exposure and Auto White Balance
- LCD display to show camera status
- Video conferencing mode
- Twain/VFW driver for Windows 98SE/ME/2000/XP
- Use 1 x AAA size Alkaline battery
- Fixed Focus
- Weight about 30 grams
- Dimension: 2.5"(L) x 1.8"(H) x 1.1"(D)

Specifications are subject to change without notice.